

## CHLORINE (RESIDUAL)

Approved by Standard Methods Committee, 2000. Editorial revisions, 2021.

### 4500-Cl A. INTRODUCTION

#### 1. Effects of Chlorination

The chlorination of water supplies and polluted waters serves primarily to destroy or deactivate disease-producing microorganisms. A secondary benefit, particularly in treating drinking water, is the overall improvement in water quality resulting from the reaction of chlorine with ammonia, iron, manganese, sulfide, and some organic substances.

Chlorination may produce adverse effects. Taste and odor characteristics of phenols and other organic compounds present in a water supply may be intensified. Potentially carcinogenic chloroorganic compounds, such as chloroform, may be formed. Combined chlorine formed on chlorination of ammonia- or amine-bearing waters adversely affects some aquatic life. To fulfill the primary purpose of chlorination and to minimize any adverse effects, it is essential that proper testing procedures be used with a foreknowledge of the limitations of the analytical determination.

#### 2. Chlorine Forms and Reactions

Chlorine applied to water in its molecular or hypochlorite form initially undergoes hydrolysis to form free chlorine consisting of aqueous molecular chlorine, hypochlorous acid, and hypochlorite ion. The relative proportion of these free chlorine forms is pH- and temperature-dependent. At the pH of most waters, hypochlorous acid and hypochlorite ion predominate.

Free chlorine reacts readily with ammonia and certain nitrogenous compounds to form combined chlorine. With ammonia, chlorine reacts to form the chloramines: monochloramine, dichloramine, and nitrogen trichloride. The presence and concentrations of these combined forms depend chiefly on pH, temperature, initial chlorine-to-nitrogen ratio, absolute chlorine demand, and reaction time. Both free and combined chlorine may be present simultaneously. Combined chlorine in water supplies may be formed in the treatment of raw waters containing ammonia or by the addition of ammonia or ammonium salts. Chlorinated wastewater effluents and certain chlorinated industrial effluents normally contain only combined chlorine. Historically, the principal analytical problem has been to distinguish between free and combined forms of chlorine.

#### 3. Selection of Method

In two separate but related studies, samples were prepared and distributed to participating laboratories to evaluate chlorine methods. Because of poor accuracy and precision and a high

overall (average) total error in these studies, all orthotolidine procedures except one were dropped in the 14th Edition of this work. The useful stabilized neutral orthotolidine method was deleted from the 15th Edition because of the toxic nature of orthotolidine. The leuco crystal violet (LCV) procedure was dropped from the 17th Edition because of its relative difficulty and the lack of comparative advantages.

*a. Natural and treated waters:* The iodometric methods (4500-Cl B and C) are suitable for measuring total chlorine concentrations greater than 1 mg/L, but the amperometric endpoint of 4500-Cl C and D gives greater sensitivity. All acidic iodometric methods suffer from interferences, generally in proportion to the quantity of potassium iodide (KI) and H<sup>+</sup> added.

The amperometric titration method (4500-Cl D) is a standard of comparison for the determination of free or combined chlorine. It is affected little by common oxidizing agents, temperature variations, turbidity, and color. The method is not as simple as the colorimetric methods and requires greater operator skill to obtain the best reliability. Loss of chlorine can occur because of rapid stirring in some commercial equipment. Clean and conditioned electrodes are necessary for sharp endpoints.

A low-level amperometric titration procedure (4500-Cl E) has been added to determine total chlorine at levels below 0.2 mg/L. This method is recommended only when quantification of such low residuals is necessary. The interferences are similar to those found with the standard amperometric procedure (4500-Cl D). The DPD methods (4500-Cl F and G) are operationally simpler for determining free chlorine than the amperometric titration. Procedures are given for estimating the separate mono- and dichloramine and combined fractions. High concentrations of monochloramine interfere with the free chlorine determination unless the reaction is stopped with arsenite or thioacetamide. In addition, the DPD methods are subject to interference by oxidized forms of manganese unless compensated for by a blank.

The amperometric and DPD methods are unaffected by dichloramine concentrations in the range of 0 to 9 mg/L Cl as Cl<sub>2</sub> in the determination of free chlorine. Nitrogen trichloride, if present, may react partially as free chlorine in the amperometric, DPD, and FACTS methods. The extent of this interference in the DPD methods does not appear to be significant.

The free chlorine test, syringaldazine (FACTS, 4500-Cl H) was developed specifically for free chlorine. It is unaffected by significant concentrations of monochloramine, dichloramine, nitrate, nitrite, and oxidized forms of manganese.<sup>1</sup>

Sample color and turbidity may interfere in all colorimetric procedures.

Organic contaminants may produce a false free chlorine reading in most colorimetric methods (see ¶ *b* below). Many strong oxidizing agents interfere in the measurement of free chlorine in all methods. Such interferences include bromine, chlorine dioxide, iodine, permanganate, hydrogen peroxide, and ozone. However, the reduced forms of these compounds—bromide, chloride, iodide, manganous ion, and oxygen, in the absence of other oxidants, do not interfere. Reducing agents, such as ferrous compounds, hydrogen sulfide, and oxidizable organic matter, generally do not interfere.

*b. Wastewaters:* The determination of total chlorine in samples containing organic matter presents special problems. Because of the presence of ammonia, amines, and organic compounds, particularly organic nitrogen, residual chlorine exists in a combined state. A considerable residual may exist in this form, but at the same time there may be appreciable unsatisfied chlorine demand. Addition of reagents in the determination may change these relationships so residual chlorine is lost during the analysis. Only the DPD method for total chlorine is performed under neutral pH conditions. In wastewater, the differentiation between free chlorine and combined chlorine ordinarily is not made because wastewater chlorination seldom is carried far enough to produce free chlorine.

The determination of residual chlorine in industrial wastes is similar to that in domestic wastewater when the waste contains organic matter, but may be similar to the determination in water when the waste is low in organic matter.

None of these methods is applicable to estuarine or marine waters because the bromide is converted to bromine and bromamines, which are detected as free or total chlorine. A procedure for estimating this interference is available for the DPD method.

Although the methods given below are useful for the determination of residual chlorine in wastewaters and treated effluents, select the method in accordance with sample composition. Some industrial wastes, or mixtures of wastes with domestic wastewater, may require special precautions and modifications to obtain satisfactory results.

Determine free chlorine in wastewater by any of the methods provided that known interfering substances are absent or appropriate correction techniques are used. The amperometric method is the method of choice because it is not subject to interference from color, turbidity, iron, manganese, or nitrite nitrogen. The DPD method is subject to interference from high concentrations of monochloramine, which is avoided by adding thioacetamide immediately after reagent addition. Oxidized forms of manganese at all levels encountered in water will interfere in all methods except in the free chlorine measurement of amperometric titrations and FACTS, but a blank correction for manganese can be made in 4500-Cl F and G.

The FACTS method is unaffected by concentrations of monochloramine, dichloramine, nitrite, iron, manganese, and other interfering compounds normally found in domestic wastewaters.

For total chlorine in samples containing significant amounts of organic matter, use either the DPD methods (4500-Cl F and G), amperometric, or iodometric back titration method (4500-Cl C) to prevent contact between the full concentration of liberated iodine and the sample. With 4500-Cl C, do not use the starch-iodide endpoint if the concentration is less than 1 mg/L. In the absence of interference, the amperometric and starch-iodide endpoints give concordant results. The amperometric endpoint is inherently more

sensitive and is free of interference from color and turbidity, which can cause difficulty with the starch-iodide endpoint. On the other hand, certain metals, surface-active agents, and complex anions in some industrial wastes interfere in the amperometric titration and indicate the need for another method for such wastewaters. Silver in the form of soluble silver cyanide complex, in concentrations of 1.0 mg/L Ag, poisons the cell at pH 4.0 but not at 7.0. The silver ion, in the absence of the cyanide complex, gives extensive response in the current at pH 4.0 and gradually poisons the cell at all pH levels. Cuprous copper in the soluble copper cyanide ion, in concentrations of 5 mg/L Cu or less, poisons the cell at pH 4.0 and 7.0. Although iron and nitrite may interfere with this method, minimize the interference by buffering to pH 4.0 before adding KI. Oxidized forms of manganese interfere in all methods for total chlorine including amperometric titration. An unusually high content of organic matter may cause uncertainty in the endpoint.

Regardless of endpoint detection, either phenylarsine oxide or thiosulfate may be used as the standard reducing reagent at pH 4. The former is more stable and is preferred.

The DPD titrimetric and colorimetric methods (4500-Cl F and G, respectively) are applicable to determining total chlorine in polluted waters. In addition, both DPD procedures and the amperometric titration method allow for estimating monochloramine and dichloramine fractions. Because all methods for total chlorine depend on the stoichiometric production of iodine, waters containing iodine-reducing substances may not be analyzed accurately by these methods, especially where iodine remains in the solution for a significant time. This problem occurs in 4500-Cl B and D. The back titration procedure (4500-Cl C) and 4500-Cl F and G cause immediate reaction of the iodine generated so it has little chance to react with other iodine-reducing substances.

In all colorimetric procedures, compensate for color and turbidity by using color and turbidity blanks.

A method (4500-Cl I) for total residual chlorine using a potentiometric iodide electrode is proposed. This method is suitable for the analysis of chlorine residuals in natural and treated waters and wastewater effluents. No differentiation of free and combined chlorine is possible. This procedure is an adaptation of other iodometric techniques and is subject to the same inferences.

#### 4. Sampling and Storage

Chlorine in aqueous solution is not stable, and the chlorine content of samples or solutions, particularly weak solutions, decreases rapidly. Exposure to sunlight or other strong light or agitation accelerates the reduction of chlorine. Therefore, begin chlorine determinations immediately after sampling, avoiding excessive light and agitation. Do not store samples to be analyzed for chlorine.

#### Reference

- Cooper WJ, Roscher NM, Slifker RA. Determining free available chlorine by DPD-colorimetric, DPD-steadifac (colorimetric) and FACTS procedures. *J Amer Water Works Assoc.* 1982;74(7):362–368.

#### Bibliography

- Marks HC, Williams DB, Glasgow GU. Determination of residual chlorine compounds. *J Amer Water Works Assoc.* 1951;43(3):201–207.

Nicolson NJ. An evaluation of the methods for determining residual chlorine in water, Part 1. Free chlorine. *Analyst*. 1965;90(1069): 187-198.

Whittle GP, Lapteff Jr A. New analytical techniques for the study of water disinfection. In: *Chemistry of water supply, treatment, and*

distribution. Ann Arbor (MI): Ann Arbor Science Publishers; 1973, p. 63.

Guter WJ, Cooper WJ, Sorber CA. Evaluation of existing field test kits for determining free chlorine residuals in aqueous solutions. *J Amer Water Works Assoc*. 1974;66(1):38-43.

## 4500-Cl B. IODOMETRIC METHOD I

### 1. General Discussion

*a. Principle:* Chlorine liberates free iodine from potassium iodide (KI) solutions at pH 8 or less. The liberated iodine is titrated with a standard solution of sodium thiosulfate ( $\text{Na}_2\text{S}_2\text{O}_3$ ) with starch as the indicator. Titrate at pH 3 to 4 because the reaction is not stoichiometric at neutral pH due to the partial oxidation of thiosulfate to sulfate.

*b. Interference:* Oxidized forms of manganese and other oxidizing agents interfere. Reducing agents, such as organic sulfides, also interfere. Although the neutral titration minimizes the interfering effect of ferric and nitrite ions, the acid titration is preferred because some forms of combined chlorine do not react at pH 7. Use only acetic acid for the acid titration. Sulfuric acid ( $\text{H}_2\text{SO}_4$ ) increases interferences. Never use hydrochloric acid (HCl). See 4500-Cl A.3 for a discussion of other interferences.

*c. Minimum detectable concentration:* The minimum detectable concentration approximates 40  $\mu\text{g/L}$  Cl as  $\text{Cl}_2$  if 0.01 N  $\text{Na}_2\text{S}_2\text{O}_3$  is used with a 1000-mL sample. Concentrations below 1 mg/L cannot be determined accurately by the starch-iodide endpoint used in this method. Lower concentrations can be measured with the amperometric endpoint in 4500-Cl C and D.

*d. Quality control (QC):* The QC practices considered to be an integral part of each method are summarized in Table 4020:1.

### 2. Reagents

*a. Acetic acid, conc (glacial).*

*b. Potassium iodide (KI), crystals.*

*c. Standard sodium thiosulfate, 0.1 N:* Dissolve 25 g  $\text{Na}_2\text{S}_2\text{O}_3 \cdot 5\text{H}_2\text{O}$  in 1 L freshly boiled reagent water and standardize against potassium bi-iodate or potassium dichromate after at least 2 weeks storage. This initial storage is necessary to allow the oxidation of any bisulfite ion present. Use boiled reagent water and add a few milliliters of chloroform ( $\text{CHCl}_3$ ) to minimize bacterial decomposition.

Standardize 0.1 N  $\text{Na}_2\text{S}_2\text{O}_3$  by one of the following:

1) Iodate method—Dissolve 3.249 g anhydrous potassium bi-iodate,  $\text{KH}(\text{IO}_3)_2$ , primary standard quality, or 3.567 g  $\text{KIO}_3$  dried at  $103 \pm 2^\circ\text{C}$  for 1 h, in reagent water and dilute to 1000 mL to yield a 0.1000 N solution. Store in a glass-stoppered bottle.

To 80 mL reagent water, add, with constant stirring, 1 mL conc  $\text{H}_2\text{SO}_4$ , 10.00 mL 0.1000 N  $\text{KH}(\text{IO}_3)_2$ , and 1 g KI. Titrate immediately with 0.1 N  $\text{Na}_2\text{S}_2\text{O}_3$  titrant until the yellow color of the liberated iodine almost is discharged. Add 1 mL starch indicator solution and continue titrating until the blue color disappears.

2) Dichromate method—Dissolve 4.904 g anhydrous potassium dichromate,  $\text{K}_2\text{Cr}_2\text{O}_7$ , of primary standard quality, in

reagent water and dilute to 1000 mL to yield a 0.1000 N solution. Store in a glass-stoppered bottle.

Proceed as in the iodate method, with the following exceptions: Substitute 10.00 mL 0.1000 N  $\text{K}_2\text{Cr}_2\text{O}_7$  for iodate and let the reaction mixture stand 6 min in the dark before titrating with 0.1 N  $\text{Na}_2\text{S}_2\text{O}_3$  titrant.

$$\text{Normality } \text{Na}_2\text{S}_2\text{O}_3 = \frac{1}{\text{mL } \text{Na}_2\text{S}_2\text{O}_3 \text{ consumed}}$$

*d. Standard sodium thiosulfate titrant, 0.01 N or 0.025 N:* Improve the stability of 0.01 N or 0.025 N  $\text{Na}_2\text{S}_2\text{O}_3$  by diluting an aged 0.1 N solution, made as directed above, with freshly boiled reagent water. Add 4 g sodium borate and 10 mg/L mercuric iodide solution. For accurate work, standardize this solution daily in accordance with the directions given above, using 0.01 N or 0.025 N iodate or  $\text{K}_2\text{Cr}_2\text{O}_7$ . Use sufficient volumes of these standard solutions so their final dilution is not greater than 1 + 4. To speed up operations where many samples must be titrated use an automatic buret of a type in which rubber does not come in contact with the solution. Standard titrants, 0.0100 N and 0.0250 N, are equivalent, respectively, to 354.5  $\mu\text{g}$  and 886.3  $\mu\text{g}$  Cl as  $\text{Cl}_2$  per 1.00 mL.

*e. Starch indicator solution:* To 5 g starch (potato, arrowroot, or soluble), add a little cold water and grind in a mortar to a thin paste. Pour into 1 L of boiling reagent water, stir, and let settle overnight. Preserve the clear supernate with 1.25 g salicylic acid, 4 g zinc chloride, or a combination of 4 g sodium propionate and 2 g/L sodium azide starch solution. Some commercial starch substitutes are satisfactory.

*f. Standard iodine, 0.1 N:* See 4500-Cl C.3g.

*g. Dilute standard iodine, 0.0282 N:* See 4500-Cl C.3h.

### 3. Procedure

*a. Volume of sample:* Select a sample volume that requires no more than 20 mL 0.01 N  $\text{Na}_2\text{S}_2\text{O}_3$  and no less than 0.2 mL for the starch-iodide endpoint. For a chlorine range of 1 to 10 mg/L, use a 500-mL sample; above 10 mg/L, use proportionately less sample. Use smaller samples and volumes of titrant with the amperometric endpoint.

*b. Preparation for titration:* Place 5 mL acetic acid, or enough to reduce the pH to between 3.0 and 4.0, in a flask or white porcelain casserole. Add about 1 g KI estimated on a spatula. Pour the sample in and mix with a stirring rod.

*c. Titration:* Titrate away from direct sunlight. Add 0.025 N or 0.01 N  $\text{Na}_2\text{S}_2\text{O}_3$  from a buret until the yellow color of the liberated

iodine almost is discharged. Add 1 mL starch solution and titrate until the blue color is discharged.

If the titration is made with 0.025 N  $\text{Na}_2\text{S}_2\text{O}_3$  instead of 0.01 N, then, with a 1-L sample, 1 drop is equivalent to about 50  $\mu\text{g/L}$ . It is not possible to discern the endpoint with greater accuracy.

*d. Blank titration:* Take a volume of reagent water corresponding to the sample used for titration in 4500-Cl B.3a–c, add 5 mL acetic acid, 1 g KI, and 1 mL starch solution and titrate as in paragraphs 1 or 2 below, whichever applies.

1) If a blue color develops, titrate with 0.01 N or 0.025 N  $\text{Na}_2\text{S}_2\text{O}_3$  to the disappearance of the blue color and record the result. *B* (see 4500-Cl B.4) is negative.

2) If no blue color occurs, titrate with 0.0282 N iodine solution until a blue color appears. Back-titrate with 0.01 N or 0.025 N  $\text{Na}_2\text{S}_2\text{O}_3$  and record the difference. *B* is positive.

Before calculating the chlorine concentration, subtract the blank titration of paragraph 1 above from the sample titration; or, if necessary, add the net equivalent value of the blank titration of paragraph 2 above.

#### 4. Calculation

For standardizing a chlorine solution for temporary standards:

$$\text{mg/mL Cl as Cl}_2 = \frac{(A \pm B) \times N \times 35.45}{\text{mL sample}}$$

For determining total available residual chlorine in a water sample:

$$\text{mg/L Cl as Cl}_2 = \frac{(A \pm B) \times N \times 35.45}{\text{mL sample}}$$

where:

*A* = mL titration for sample,

*B* = mL titration for blank (positive or negative), and

*N* = normality of  $\text{Na}_2\text{S}_2\text{O}_3$ .

#### 5. Precision and Bias

Published studies<sup>1,2</sup> give the results of 9 methods used to analyze synthetic water samples without interferences. Variations of some of the methods appear in this edition. More current data are not now available.

#### References

1. Lishka RJ, Mcfarren EF, Parker JH. Water chlorine (residual) No. 1: Report Number 35: Report of a study conducted by Analytical Reference Service. Cincinnati (OH): U.S. Public Health Service, Consumer Protection and Environmental Health Service, Environmental Control Administration; 1969.
2. Lishka RJ, Mcfarren RF. Water chlorine (residual) No. 2: Report Number 40: Report of a study conducted by Analytical Reference Service. Cincinnati (OH): Water Hygiene Division, Office of Water Programs, U.S. Environmental Protection Agency; 1971.

#### Bibliography

- Lea C. Chemical control of sewage chlorination. The use and value of orthotolidine test. *J Soc Chem Ind. (London)* 1933;52:245T.
- American Water Works Association. 1943. Committee report: Control of chlorination. *J Amer Water Works Assoc.* 1943;35(10):1315–1328.
- Marks HC, Joiner R, Strandskov FB. Amperometric titration of residual chlorine in sewage. *Water Sewage Works* 1948;95(5):175–178.
- Strandskov FB, Marks HC, Horschier DH. Application of a new residual chlorine method to effluent chlorination. *Sewage Works J.* 1949;21(1):23–30.
- Nusbaum I, Meyerson LA. Determination of chlorine demands and chlorine residuals in sewage. *Sewage Ind Wastes.* 1951;23(8):968–976.
- Marks HC, Chamberlin NS. Determination of residual chlorine in metal finishing wastes. *Anal Chem.* 1953;24(12):1885–1887.

## (4500-Cl) C. IODOMETRIC METHOD II

### 1. General Discussion

*a. Principle:* In this method, used for wastewater analysis, the endpoint signal is reversed because the unreacted standard reducing agent (phenylarsine oxide or thiosulfate) remaining in the sample is titrated with standard iodine or standard iodate, rather than directly titrating the iodine released. This indirect procedure is necessary regardless of the method of endpoint detection, to avoid contact between the full concentration of liberated iodine and the wastewater.

When iodate is used as a back titrant, use only phosphoric acid. Do not use acetate buffer.

*b. Interference:* Oxidized forms of manganese and other oxidizing agents give positive interferences. Reducing agents, such as organic sulfides, do not interfere as much as in 4500-Cl B. Minimize iron and nitrite interference by buffering to pH 4.0

before adding potassium iodide (KI). An unusually high content of organic matter may cause some uncertainty in the endpoint. Whenever manganese, iron, and other interferences definitely are absent, reduce this uncertainty and improve precision by acidifying to pH 1.0. Control interference from more than 0.2 mg/L nitrite with phosphoric acid-sulfamic acid reagent. A larger fraction of organic chloramines react at a lower pH along with interfering substances. See 4500-Cl A.3 for a discussion of other interferences.

*c. Quality control (QC):* The QC practices considered to be an integral part of each method are summarized in Table 4020:1.

### 2. Apparatus

For a description of the amperometric endpoint detection apparatus and a discussion of its use, see 4500-Cl D.2a.

### 3. Reagents

*a. Standard phenylarsine oxide solution, 0.005 64 N:* Dissolve approximately 0.8 g phenylarsine oxide powder in 150 mL 0.3 N NaOH solution. After settling, decant 110 mL into 800 mL reagent water and mix thoroughly. Bring to pH 6 to 7 with 6 N HCl and dilute to 950 mL with reagent water. **Caution: Severe poison. Suspected carcinogen.**

Standardization—Accurately measure 5 to 10 mL freshly standardized 0.0282 N iodine solution into a flask and add 1 mL KI solution. Titrate with phenylarsine oxide solution, using the amperometric endpoint (4500-Cl D) or starch solution (see 4500-Cl B.2e) as an indicator. Adjust to 0.005 64 N and recheck against the standard iodine solution; 1.00 mL = 200 µg available chlorine. **(Caution: Toxic—take care to avoid ingestion.)**

*b. Standard sodium thiosulfate solution, 0.1 N:* See 4500-Cl B.2c.

*c. Standard sodium thiosulfate solution, 0.005 64 N:* Prepare by diluting 0.1 N Na<sub>2</sub>S<sub>2</sub>O<sub>3</sub>. For maximum stability of the dilute solution, prepare by diluting an aged 0.1 N solution with freshly boiled reagent water (to minimize bacterial action) and add 4 g/L Na<sub>4</sub>B<sub>4</sub>O<sub>7</sub>. To inhibit mold formation optionally add either 10 mg HgI<sub>2</sub> or 2 drops toluene per liter of solution. Standardize daily as directed in 4500-Cl B.2c using 0.005 64 N K<sub>2</sub>Cr<sub>2</sub>O<sub>7</sub> or iodate solution. Use sufficient volume of sample so the final dilution does not exceed 1 + 2. Use an automatic buret of a type in which rubber does not come in contact with the solution. 1.00 mL = 200 µg available chlorine.

*d. Potassium iodide (KI), crystals.*

*e. Acetate buffer solution, pH 4.0:* Dissolve 146 g anhydrous NaC<sub>2</sub>H<sub>3</sub>O<sub>2</sub>, or 243 g NaC<sub>2</sub>H<sub>3</sub>O<sub>2</sub> · 3H<sub>2</sub>O, in 400 mL reagent water, add 480 g conc acetic acid, and dilute to 1 L with chlorine-demand-free water.

*f. Standard arsenite solution, 0.1 N:* Accurately weigh a stoppered weighing bottle containing approximately 4.95 g arsenic trioxide, As<sub>2</sub>O<sub>3</sub>. Transfer without loss to a 1-L volumetric flask and again weigh bottle. Do not attempt to brush out adhering oxide. Moisten As<sub>2</sub>O<sub>3</sub> with water and add 15 g NaOH and 100 mL reagent water. Swirl flask contents gently to dissolve. Dilute to 250 mL with reagent water and saturate with CO<sub>2</sub>, thus converting all NaOH to NaHCO<sub>3</sub>. Dilute to mark, stopper, and mix thoroughly. This solution will preserve its titer almost indefinitely. **(Caution: Severe poison. Suspected carcinogen.)**

$$\text{Normality} = \frac{\text{g As}_2\text{O}_3}{49.455}$$

*g. Standard iodine solution, 0.1 N:* Dissolve 40 g KI in 25 mL chlorine-demand-free water, add 13 g resublimed iodine, and stir until dissolved. Transfer to a 1-L volumetric flask and dilute to mark.

Standardization—Accurately measure 40 to 50 mL 0.1 N arsenite solution into a flask and titrate with 0.1 N iodine solution, using starch solution as indicator. To obtain accurate results, ensure that the solution is saturated with CO<sub>2</sub> at end of titration by passing current of CO<sub>2</sub> through solution for a few minutes just before endpoint is reached, or add a few drops of HCl to liberate sufficient CO<sub>2</sub> to saturate solution. Alternatively, standardize against Na<sub>2</sub>S<sub>2</sub>O<sub>3</sub>; see 4500-Cl B.2c1.

Optionally, prepare 0.1000 N iodine solution directly as a standard solution by weighing 12.69 g primary standard resublimed iodine. Because I<sub>2</sub> may be volatilized and lose from both solid and solution, transfer the solid immediately to KI as specified above. Never let the solution stand in open containers for extended periods.

*h. Standard iodine titrant, 0.0282 N:* Dissolve 25 g KI in a little distilled water in a 1-L volumetric flask, add correct amount of 0.1 N iodine solution exactly standardized to yield a 0.0282 N solution, and dilute to 1 L with chlorine-demand-free water. For accurate work, standardize daily according to directions in paragraph *g* above, using 5 to 10 mL of arsenite or Na<sub>2</sub>S<sub>2</sub>O<sub>3</sub> solution. Store in amber bottles or in the dark; protect solution from direct sunlight at all times and keep from all contact with rubber.

*i. Starch indicator:* See 4500-Cl B.2e.

*j. Standard iodate titrant, 0.005 64 N:* Dissolve 201.2 mg primary standard grade KIO<sub>3</sub>, dried for 1 h at 103 °C, or 183.3 mg primary standard anhydrous potassium bi-iodate in reagent water and dilute to 1 L.

*k. Phosphoric acid solution (H<sub>3</sub>PO<sub>4</sub>), 1 + 9.*

*l. Phosphoric acid-sulfamic acid solution:* Dissolve 20 g NH<sub>2</sub>SO<sub>3</sub>H in 1 L 1 + 9 phosphoric acid.

*m. Chlorine-demand-free water:* Prepare chlorine-demand-free water from good-quality reagent water by adding sufficient chlorine to give 5 mg/L free chlorine. After standing 2 d this solution should contain at least 2 mg/L free chlorine; if not, discard and obtain better-quality water. Remove remaining free chlorine by placing container in sunlight or irradiating with an ultraviolet lamp. After several hours take sample, add KI, and measure total chlorine with a colorimetric method using a Nessler tube to increase sensitivity. Do not use before last trace of free and combined chlorine has been removed.

Distilled water commonly contains ammonia and also may contain reducing agents. Collect good-quality reagent water in a sealed container from which water can be drawn by gravity. To the air inlet of the container add an H<sub>2</sub>SO<sub>4</sub> trap consisting of a large test tube half filled with 1 + 1 H<sub>2</sub>SO<sub>4</sub> connected in series with a similar but empty test tube. Fit both test tubes with stoppers and inlet tubes terminating near the bottom of the tubes and outlet tubes terminating near the top of the tubes. Connect the outlet tube of the trap containing H<sub>2</sub>SO<sub>4</sub> to the distilled water container, and connect the inlet tube to the outlet of the empty test tube. The empty test tube prevents discharge to the atmosphere of H<sub>2</sub>SO<sub>4</sub> due to temperature-induced pressure changes. Stored in such a container, chlorine-demand-free water is stable for several weeks unless bacterial growth occurs.

### 4. Procedure

*a. Preparation for titration:*

1) Volume of sample—For chlorine concentration of 10 mg/L or less, titrate 200 mL. For greater chlorine concentrations, use proportionately less sample and dilute to 200 mL with chlorine-demand-free water. Use a sample of such size that not more than 10 mL phenylarsine oxide solution is required.

2) Preparation for titration—Measure 5 mL 0.005 64 N phenylarsine oxide or thiosulfate for chlorine concentrations from 2 to 5 mg/L, and 10 mL for concentrations of 5 to 10 mg/L, into a flask or casserole for titration with standard iodine or iodate. Start stirring. For titration by amperometry or standard iodine, also add

excess KI (approximately 1 g) and 4 mL acetate buffer solution or enough to reduce the pH to between 3.5 and 4.2.

*b. Titration:* Use one of the following:

1) Amperometric titration—Add 0.0282 N iodine titrant in small increments from a 1-mL buret or pipet. Observe the meter needle response as iodine is added. The pointer remains practically stationary until the endpoint is approached, whereupon each iodine increment causes a temporary deflection of the microammeter, with the pointer dropping back to its original position. Stop the titration at the endpoint when a small increment of iodine titrant gives a definite pointer deflection upscale and the pointer does not return promptly to its original position. Record the volume of iodine titrant used to reach the endpoint.

2) Colorimetric (iodine) titration—Add 1 mL starch solution and titrate with 0.0282 N iodine to the first appearance of blue color that persists after complete mixing.

3) Colorimetric (iodate) titration—To a suitable flask or casserole add 200 mL chlorine-demand-free water and add, with agitation, the required volume of reductant, an excess of KI (approximately 0.5 g), 2 mL 10% H<sub>3</sub>PO<sub>4</sub> solution, and 1 mL starch solution in the order given, and titrate immediately with 0.005 64 N iodate solution to the first appearance of a blue color that persists after complete mixing. Titration may be delayed up to 10 min without appreciable error if H<sub>3</sub>PO<sub>4</sub> is not added until immediately before titration. Designate the volume of iodate solution used as *A*. Repeat the procedure, substituting 200 mL sample for the 200 mL chlorine-demand-free water. If the sample is colored or turbid, titrate to the first change in color, using for

comparison another portion of sample with H<sub>3</sub>PO<sub>4</sub> added. Designate this volume of iodate solution as *B*.

## 5. Calculation

*a. Titration with standard iodine:*

$$\text{mg/L Cl as Cl}_2 = \frac{(A - 5B) \times 200}{C}$$

where:

*A* = mL 0.005 64 N reductant,

*B* = mL 0.0282 N I<sub>2</sub>, and

*C* = mL sample.

*b. Titration with standard iodate:*

$$\text{mg/L Cl as Cl}_2 = \frac{(A - B) \times 200}{C}$$

where:

*A* = mL Na<sub>2</sub>S<sub>2</sub>O<sub>3</sub>,

*B* = mL iodate required to titrate Na<sub>2</sub>S<sub>2</sub>O<sub>3</sub>, and

*C* = mL sample.

## Bibliography

See 4500-Cl B.7.

# 4500-Cl D. AMPEROMETRIC TITRATION METHOD

## 1. General Discussion

Amperometric titration requires a higher degree of skill and care than the colorimetric methods. Chlorine residuals over 2 mg/L are measured best by means of smaller samples or by dilution with water that has neither residual chlorine nor a chlorine demand. The method can be used to determine total chlorine and can differentiate between free and combined chlorine. A further differentiation into monochloramine and dichloramine fractions is possible by control of KI concentration and pH.

*a. Principle:* The amperometric method is a special adaptation of the polarographic principle. Free chlorine is titrated at a pH between 6.5 and 7.5, a range in which the combined chlorine reacts slowly. The combined chlorine, in turn, is titrated in the presence of the proper amount of KI in the pH range 3.5 to 4.5. When free chlorine is determined, the pH must not be greater than 7.5 because the reaction becomes sluggish at higher pH values, nor less than 6.5 because at lower pH values some combined chlorine may react even in the absence of iodide. When combined chlorine is determined, the pH must not be less than 3.5 because of increased interferences at lower pH values, nor greater than 4.5 because the iodide reaction is not quantitative at higher pH values. The tendency of monochloramine to react more readily with iodide than does dichloramine provides a means for further

differentiation. The addition of a small amount of KI in the neutral pH range enables estimation of monochloramine content. Lowering the pH into the acid range and increasing the KI concentration allows the separation determination of dichloramine.

Organic chloramines can be measured as free chlorine, monochloramine, or dichloramine, depending on the activity of chlorine in the organic compound.

Phenylarsine oxide is stable even in dilute solution and each mole reacts with 2 equivalents of halogen. A special ampere-metric cell is used to detect the endpoint of the residual chlorine-phenylarsine oxide titration. The cell consists of a nonpolarizable reference electrode that is immersed in a salt solution and a readily polarizable noble-metal electrode that is in contact with both the salt solution and the sample being titrated. In some applications, endpoint selectivity is improved by adding +200 mV to the platinum electrode versus silver, silver chloride. Another approach to endpoint detection uses dual platinum electrodes, a mercury cell with voltage divider to impress a potential across the electrodes, and a microammeter. If there is no chlorine residual in the sample, the microammeter reading will be comparatively low because of cell polarization. The greater the residual, the greater the microammeter reading. The meter acts merely as a null-point indicator—that is, the actual meter reading is not important, but rather the relative readings as the titration proceeds. The gradual

addition of phenylarsine oxide causes the cell to become more and more polarized because of the decrease in chlorine. The end-point is recognized when no further decrease in meter reading can be obtained by adding more phenylarsine oxide.

*b. Interference:* Accurate determinations of free chlorine cannot be made in the presence of nitrogen trichloride,  $\text{NCl}_3$ , or chlorine dioxide, which titrate partly as free chlorine. When present,  $\text{NCl}_3$  can titrate partly as free chlorine and partly as dichloramine, contributing a positive error in both fractions at a rate of approximately 0.1% per min. Some organic chloramines also can be titrated in each step. Monochloramine can intrude into the free chlorine fraction and dichloramine can interfere in the monochloramine fraction, especially at high temperatures and prolonged titration times. Free halogens other than chlorine also will titrate as free chlorine. Combined chlorine reacts with iodide ions to produce iodine. When titration for free chlorine follows a combined chlorine titration, which requires addition of KI, erroneous results may occur unless the measuring cell is rinsed thoroughly with distilled water between titrations.

Interference from copper has been noted in samples taken from copper pipe or after heavy copper sulfate treatment of reservoirs, with metallic copper plating out on the electrode. Silver ions also poison the electrode. Interference occurs in some highly colored waters and in waters containing surface-active agents. The response of the measuring cell is slower at very low temperatures requiring a longer time for the titration, but precision is not affected. A reduction in reaction rate is caused by pH values above 7.5. Overcome this by buffering all samples to pH 7.0 or less. Some substances, such as manganese, nitrite, and iron, do not interfere. The violent stirring of some commercial titrators can lower chlorine values by volatilization. When diluting samples containing high chlorine content, take care that the dilution water is free of chlorine and ammonia and possesses no chlorine demand.

See 4500-Cl A.3 for a discussion of other interferences.

*c. Quality control (QC):* The QC practices considered to be an integral part of each method are summarized in Table 4020:1.

## 2. Apparatus

*a. Endpoint detection apparatus,* consisting of a cell unit connected to a microammeter, with necessary electrical accessories. The cell unit includes a noble-metal electrode of sufficient surface area, a salt bridge to provide an electrical connection without diffusion of electrolyte, and a reference electrode of silver-silver chloride in a saturated sodium chloride solution connected into the circuit by means of the salt bridge. Numerous commercial systems are available.

Keep platinum electrode free of deposits and foreign matter. Vigorous chemical cleaning generally is unnecessary. Occasional mechanical cleaning with a suitable abrasive usually is sufficient. Keep the salt bridge in good operating condition. Do not allow it to become plugged nor permit appreciable flow of electrolyte through it. Keep the solution surrounding the reference electrode free of contamination and maintain it at constant composition by ensuring an adequate supply of undissolved salt at all times. A cell with 2 metal electrodes polarized by a small DC potential also may be used. (See 4500-Cl D.7.)

*b. Agitator,* designed to give adequate agitation at the noble-metal electrode surface to ensure proper sensitivity. Thoroughly

clean the agitator and exposed electrode system to remove all chlorine-consuming contaminants by immersing them in water containing 1 to 2 mg/L free chlorine for a few minutes. Add KI to the same water and let the agitator and electrodes remain immersed for 5 min. After thorough rinsing with chlorine-demand-free water or the sample to be tested, the sensitized electrodes and agitator are ready for use. Remove iodide reagent completely from the cell.

*c. Buret:* Commercial titrators usually are equipped with suitable burets (1 mL). Manual burets are available.

*d. Glassware,* exposed to water containing at least 10 mg/L chlorine for 3 h or more before use and rinsed with chlorine-demand-free water.

## 3. Reagents

*a. Standard phenylarsine oxide titrant:* See 4500-Cl C.3a.

*b. Phosphate buffer solution, pH 7:* Dissolve 25.4 g anhydrous  $\text{KH}_2\text{PO}_4$  and 34.1 g anhydrous  $\text{Na}_2\text{HPO}_4$  in 800 mL reagent water. Add 2 mL sodium hypochlorite solution containing 1% chlorine and mix thoroughly. Protect from sunlight for 2 d. Determine that free chlorine still remains in the solution. Then expose to sunlight until no chlorine remains. If necessary, carry out the final dechlorination with an ultraviolet lamp. Determine that no total chlorine remains by adding KI and measuring with one of the colorimetric tests. Dilute to 1 L with reagent water and filter if any precipitate is present.

*c. Potassium iodide solution:* Dissolve 50 g KI and dilute to 1 L with freshly boiled and cooled reagent water. Store in the dark in a brown glass-stoppered bottle, preferably in the refrigerator. Discard when the solution becomes yellow.

*d. Acetate buffer solution, pH 4:* See 4500-Cl C.3e.

## 4. Procedure

*a. Sample volume:* Select a sample volume requiring no more than 2 mL phenylarsine oxide titrant. Thus, for chlorine concentrations of 2 mg/L or less, take a 200-mL sample; for chlorine levels in excess of 2 mg/L, use 100 mL or proportionately less.

*b. Free chlorine:* Unless a sample pH is known to be between 6.5 and 7.5, add 1 mL pH 7 phosphate buffer solution to produce a pH of 6.5 to 7.5. Titrate with standard phenylarsine oxide titrant, observing current changes on microammeter. Add the titrant in progressively smaller increments until all needle movement ceases. Make successive buret readings when needle action becomes sluggish, signaling the approach of the endpoint. Subtract the last very small increment that causes no needle response because of over-titration. Alternatively, use a system involving continuous current measurements and determine endpoint mathematically.

Continue titrating for combined chlorine as described in paragraph *c* below or for the separate monochloramine and dichloramine fractions as detailed in paragraphs *e* and *f*.

*c. Combined chlorine:* To the sample remaining from the free-chlorine titration add 1.00 mL KI solution and 1 mL acetate buffer solution, in that order. Titrate with phenylarsine oxide titrant to the endpoint, as above. Do not refill the buret but simply continue the titration after recording the figure for free chlorine. Again subtract the last increment to give the amount of titrant actually used in reaction with chlorine. (If titration was continued without refilling buret, this figure represents total chlorine.

Subtracting free chlorine from the total gives combined chlorine.) Wash the apparatus and sample cell thoroughly to remove iodide ion to avoid inaccuracies when the titrator is used subsequently for a free chlorine determination.

*d. Separate samples:* If desired, determine total chlorine and free chlorine on separate samples. If the sample pH is between 3.5 and 9.5 and total chlorine alone is required, treat the sample immediately with 1 mL KI solution followed by 1 mL acetate buffer solution, and titrate with phenylarsine oxide titrant as described in paragraph *c* above.

*e. Monochloramine:* After titrating for free chlorine, add 0.2 mL KI solution to the same sample and, without refilling buret, continue the titration with the phenylarsine oxide titrant to the endpoint. Subtract the last increment to obtain the net volume of titrant consumed by monochloramine.

*f. Dichloramine:* Add 1 mL acetate buffer solution and 1 mL KI solution to same sample and titrate final dichloramine fraction as described above.

## 5. Calculation

Convert individual titrations for free chlorine, combined chlorine, total chlorine, monochloramine, and dichloramine by the following equation:

$$\text{mg/L Cl as Cl}_2 = \frac{A \times 200}{\text{mL sample}}$$

where:

A = mL phenylarsine oxide titration.

## 6. Precision and Bias

See 4500-Cl B.5.

## Bibliography

- Fouk CW, Bawden AT. A new type of endpoint in electrometric titration and its application to iodimetry. *J Amer Chem Soc.* 1926;48:2045-2051.
- Marks HC, Glass JR. A new method of determining residual chlorine. *J Amer Water Works Assoc.* 1942;34(8):1227-1240.
- Haller JF, Listek SS. Determination of chloride dioxide and other active chlorine compounds in water. *Anal Chem.* 1948;20(7):639-642.
- Mahan WA. Simplified amperometric titration apparatus for determining residual chlorine in water. *Water Sewage Works.* 1949;96(5):171-174.
- Kolthoff IM, Lingane JJ. *Polarography*, 2nd ed. New York (NY): Interscience Publishers; 1952.
- Morrow JJ. Residual chlorine determination with dual polarizable electrodes. *J Amer Water Works Assoc.* 1966;58(3):363-367.

# (4500-Cl) E. LOW-LEVEL AMPEROMETRIC TITRATION METHOD

## 1. General Discussion

Detection and quantification of chlorine residuals below 0.2 mg/L require special modifications to the amperometric titration procedure. With these modifications, chlorine concentrations at the 10- $\mu\text{g/L}$  level can be detected. It is not possible to differentiate between free and combined chlorine forms. Oxidizing agents that interfere with the amperometric titration method (4500-Cl D) will interfere.

*a. Principle:* This method modifies 4500-Cl D by using a more dilute titrant and a graphical procedure to determine the endpoint.

*b. Interference:* See 4500-Cl D.1b.

*c. Quality control (QC):* The QC practices considered to be an integral part of each method are summarized in Table 4020:1.

## 2. Apparatus

See 4500-Cl D.2.

## 3. Reagents

*a. Potassium bi-iodate, 0.002 256 N:* Dissolve 0.7332 g anhydrous potassium bi-iodate,  $\text{KH}(\text{IO}_3)_2$ , in 500 mL chlorine-free distilled water and dilute to 1000 mL. Dilute 10.00 mL to 100.0 mL with chlorine-free reagent water. Use only freshly prepared solution for the standardization of phenylarsine oxide.

*b. Potassium iodide (KI), crystals.*

*c. Low-strength phenylarsine oxide titrant, 0.000 564 N:* Dilute 10.00 mL of 0.005 64 N phenylarsine oxide (see 4500-Cl C.3a) to 100.0 mL with chlorine-demand-free water (see 4500-Cl C.3m).

Standardization—Dilute 5.00 mL 0.002 256 N potassium bi-iodate to 200 mL with chlorine-free water. Add approximately 1.5 g KI and stir to dissolve. Add 1 mL acetate buffer and let stand in the dark for 6 min. Titrate using the amperometric titrator and determine the equivalence point as indicated below.

$$\text{Normality} = 0.002256 \times 5/A$$

where:

A = mL phenylarsine oxide titrant required to reach the equivalence point of standard bi-iodate.

*d. Acetate buffer solution, pH 4:* See 4500-Cl C.3e.

## 4. Procedure

Select a sample volume requiring no more than 2 mL phenylarsine oxide titrant. A 200-mL sample is adequate for samples containing less than 0.2 mg/L total chlorine.

Before beginning the titration, rinse a buret with titrant several times. Rinse a sample container with reagent water and then with sample. Add 200 mL sample to the sample container and approximately 1.5 g KI. Dissolve, using a stirrer or mixer. Add 1 mL acetate buffer and place the container in the endpoint detection

apparatus. When the current signal stabilizes, record the reading. Initially adjust the meter to a near full-scale deflection. Titrate by adding small, known, volumes of titrant. After each addition, record the cumulative volume added and current reading when the signal stabilizes. If the meter reading falls to near or below 10% of full-scale deflection, record the low reading, readjust the meter to near full-scale deflection, and record the difference between the low amount and readjusted high deflection. Add this value to all deflection readings for subsequent titrant additions. Continue adding titrant until no further meter deflection occurs. If fewer than 3 titrant additions were made before meter deflection ceased, discard the sample and repeat the analysis using smaller titrant increments.

Determine the equivalence point by plotting the total meter deflection against titrant volume added. Draw a straight line through the first several points in the plot and a second, horizontal straight line corresponding to the final total deflection in the

meter. Read the equivalence point as the volume of titrant added at the intersection of these 2 lines.

## 5. Calculation

$$\text{mg/L Cl as Cl}_2 = \frac{A \times 200 \times N}{B \times 0.00564}$$

where:

- A* = mL titrant at equivalence point,
- N* = phenylarsine oxide normality, and
- B* = sample volume (mL).

## Bibliography

Brooks AS, Seegert GL. Low-level chlorine analysis by amperometric titration. *J Water Pollut Control Fed.* 1979;51(11):2636-2640.

# (4500-Cl) F. DPD FERROUS TITRIMETRIC METHOD

## 1. General Discussion

*a. Principle:* *N,N*-diethyl-*p*-phenylenediamine (DPD) is used as an indicator in the titrimetric procedure with ferrous ammonium sulfate (FAS). Where complete differentiation of chlorine species is not required, the procedure may be simplified to give only free and combined chlorine or total chlorine.

In the absence of iodide ion, free chlorine reacts instantly with DPD indicator to produce a red color. Subsequent addition of a small amount of iodide ion acts catalytically to cause monochloramine to produce color. Addition of iodide ion to excess evokes a rapid response from dichloramine. In the presence of iodide ion, part of the nitrogen trichloride (NCl<sub>3</sub>) is included with dichloramine and part with free chlorine. A supplementary procedure based on adding iodide ion before DPD permits estimating the proportion of NCl<sub>3</sub> appearing with free chlorine.

Chlorine dioxide (ClO<sub>2</sub>) appears, to the extent of one-fifth of its total chlorine content, with free chlorine. A full response from ClO<sub>2</sub>, corresponding to its total chlorine content, may be obtained if the sample first is acidified in the presence of iodide ion and subsequently is brought back to an approximately neutral pH by adding bicarbonate ion. Bromine, bromamine, and iodine react with DPD indicator and appear with free chlorine.

Addition of glycine before the determination of free chlorine converts free chlorine to unreactive forms, with only bromine and iodine residuals remaining. Subtractions of these residuals from the residual measured without glycine permits the differentiation of free chlorine from bromine and iodine.

*b. pH control:* For accurate results careful pH control is essential. At the proper pH of 6.2 to 6.5, the red colors produced may be titrated to sharp colorless endpoints. **Titrate as soon as the red color is formed in each step.** Too low a pH in the first step tends to make the monochloramine show in the free-chlorine step and the dichloramine in the monochloramine step. Too high a pH causes dissolved oxygen to give a color.

*c. Temperature control:* In all methods for differentiating free chlorine from chloramines, higher temperatures increase the tendency for chloramines to react and lead to increased apparent free-chlorine results. Higher temperatures also increase color fading. Complete measurements rapidly, especially at higher temperature.

*d. Interference:* The most significant interfering substance likely to be encountered in water is oxidized manganese. To correct for this, place 5 mL buffer solution and 0.5 mL sodium arsenite solution in the titration flask. Add 100 mL sample and mix. Add 5 mL DPD indicator solution, mix, and titrate with standard FAS titrant until the red color is discharged. Subtract the reading from Reading *A* obtained by the normal procedure as described in 4500-Cl F.3a1 of this method or from the total chlorine reading obtained in the simplified procedure given in 4500-Cl F.3a4. If the combined reagent in powder form (see below) is used, first add KI and arsenite to the sample and mix, then add combined buffer-indicator reagent.

As an alternative to sodium arsenite use a 0.25% solution of thioacetamide, adding 0.5 mL to 100 mL sample.

Interference by copper up to approximately 10 mg/L Cu is overcome by the EDTA incorporated in the reagents. EDTA enhances stability of DPD indicator solution by retarding deterioration due to oxidation, and in the test itself, provides suppression of dissolved oxygen errors by preventing trace metal catalysis.

Chromate in excess of 2 mg/L interferes with endpoint determination. Add barium chloride to mask this interference by precipitation.

High concentrations of combined chlorine can break through into the free chlorine fraction. *If free chlorine will be measured in the presence of more than 0.5 mg/L combined chlorine, use the thioacetamide modification.* If this modification is not used, a color-development time in excess of 1 min leads to progressively greater interference from monochloramine. Adding thioacetamide (0.5 mL 0.25% solution to 100 mL) immediately after mixing DPD reagent with the sample completely stops further

reaction with combined chlorine in the free chlorine measurement. Continue immediately with the FAS titration to obtain free chlorine. Obtain total chlorine from the normal procedure (i.e., without thioacetamide).

Because high concentrations of iodide are used to measure combined chlorine and only traces of iodide greatly increase chloramine interference in free chlorine measurements, take care to avoid iodide contamination by rinsing between samples or using separate glassware.

See 4500-Cl A.3 for a discussion of other interferences.

*e. Minimum detectable concentration:* Approximately 18 µg/L Cl as Cl<sub>2</sub>. This detection limit is achievable under ideal conditions; normal working detection limits typically are higher.

*f. Quality control (QC):* The QC practices considered to be an integral part of each method are summarized in Table 4020:1.

## 2. Reagents

*a. Phosphate buffer solution:* Dissolve 24 g anhydrous Na<sub>2</sub>HPO<sub>4</sub> and 46 g anhydrous KH<sub>2</sub>PO<sub>4</sub> in reagent water. Combine with 100 mL reagent water in which 800 mg disodium ethylenediamine tetraacetate dihydrate (EDTA) have been dissolved. Dilute to 1 L with reagent water and optionally add either 20 mg HgCl<sub>2</sub> or 2 drops toluene to prevent mold growth. Interference from trace amounts of iodide in the reagents can be negated by optional addition of 20 mg HgCl<sub>2</sub> to the solution. (**Caution: HgCl<sub>2</sub> is toxic—take care to avoid ingestion.**)

*b. N,N-Diethyl-p-phenylenediamine (DPD) indicator solution:* Dissolve 1 g DPD oxalate or 1.5 g DPD sulfate pentahydrate or 1.1 g anhydrous DPD sulfate in chlorine-free reagent water containing 8 mL 1 + 3 H<sub>2</sub>SO<sub>4</sub> and 200 mg disodium EDTA. Make up to 1 L, store in a brown glass-stoppered bottle in the dark, and discard when discolored. Periodically check the solution blank for absorbance and discard when absorbance at 515 nm exceeds 0.002/cm. (The buffer and indicator sulfate are available commercially as a combined reagent in stable powder form.) **Caution: The oxalate is toxic—take care to avoid ingestion.**

*c. Standard ferrous ammonium sulfate (FAS) titrant:* Dissolve 1.106 g Fe(NH<sub>4</sub>)<sub>2</sub>(SO<sub>4</sub>)<sub>2</sub> · 6H<sub>2</sub>O in reagent water containing 1 mL 1 + 3 H<sub>2</sub>SO<sub>4</sub> and dilute to 1 L with freshly boiled and cooled reagent water. This standard may be used for 1 month and the titer checked by potassium dichromate. For this purpose add 10 mL 1 + 5 H<sub>2</sub>SO<sub>4</sub>, 5 mL conc H<sub>3</sub>PO<sub>4</sub>, and 2 mL 0.1% barium diphenylamine sulfonate indicator to a 100-mL sample of FAS and titrate with potassium dichromate to a violet endpoint that persists for 30 s. FAS titrant equivalent to 100 µg Cl as Cl<sub>2</sub> per 1.00 mL requires 20.00 mL dichromate for titration.

*d. Potassium iodide (KI), crystals.*

*e. Potassium iodide solution:* Dissolve 500 mg KI and dilute to 100 mL, using freshly boiled and cooled reagent water. Store in a brown glass-stoppered bottle, preferably in a refrigerator. Discard when the solution becomes yellow.

*f. Potassium dichromate solution, 0.691 g to 1000 mL.*

*g. Barium diphenylaminesulfonate, 0.1%:* Dissolve 0.1 g (C<sub>6</sub>H<sub>5</sub>NHC<sub>6</sub>H<sub>4</sub>-4-SO<sub>3</sub>)<sub>2</sub>Ba in 100 mL reagent water.

*h. Sodium arsenite solution:* Dissolve 5.0 g NaAsO<sub>2</sub> in reagent water and dilute to 1 L. (**Caution: Toxic—take care to avoid ingestion.**)

*i. Thioacetamide solution:* Dissolve 250 mg CH<sub>3</sub>CSNH<sub>2</sub> in 100 mL reagent water. (**Caution: Suspected carcinogen. Take care to avoid skin contact or ingestion.**)

*j. Chlorine-demand-free water:* See 4500-Cl C.3m.

*k. Glycine solution:* Dissolve 20 g glycine (aminoacetic acid) in sufficient chlorine-demand-free water to bring to 100 mL total volume. Store under refrigerated conditions and discard if cloudiness develops.

*l. Barium chloride crystals (BaCl<sub>2</sub> · 2H<sub>2</sub>O).*

## 3. Procedure

The quantities given below are suitable for concentrations of total chlorine up to 5 mg/L. If total chlorine exceeds 5 mg/L, use a smaller sample and dilute to a total volume of 100 mL. Mix usual volumes of buffer reagent and DPD indicator solution, or usual amount of DPD powder, with reagent water *before* adding sufficient sample to bring the total volume to 100 mL. (If sample is added before buffer, the test does not work.)

If chromate is present (>2 mg/L) add and mix 0.2 g BaCl<sub>2</sub> · 2H<sub>2</sub>O per 100 mL sample before adding other reagents. If, in addition, sulfate is >500 mg/L, use 0.4 g BaCl<sub>2</sub> · 2H<sub>2</sub>O per 100 mL sample.

*a. Free chlorine or chloramine:* Place 5 mL each of buffer reagent and DPD indicator solution in a titration flask and mix (or use about 500 mg DPD powder). Add 100 mL sample, or diluted sample, and mix.

1) Free chlorine—Titrate rapidly with standard FAS titrant until the red color is discharged (Reading A).

2) Monochloramine—Add one very small crystal of KI (about 0.5 mg) or 0.1 mL (2 drops) KI solution and mix. Continue titrating until the red color is discharged again (Reading B).

3) Dichloramine—Add several crystals KI (about 1 g) and mix to dissolve. Let stand for 2 min and continue titrating until the red color is discharged (Reading C). For dichloramine concentrations greater than 1 mg/L, let stand 2 min more if color driftback indicates a slightly incomplete reaction. When dichloramine concentrations are not expected to be high, use half the specified amount of KI.

4) Simplified procedure for free and combined chlorine or total chlorine—Omit paragraph *a2* above to obtain monochloramine and dichloramine together as combined chlorine. To obtain total chlorine in one reading, add the full amount of KI at the start, with the specified amounts of buffer reagent and DPD indicator, and titrate after 2 min standing.

*b. Nitrogen trichloride:* Place one very small crystal of KI (about 0.5 mg) or 0.1 mL KI solution in a titration flask. Add 100 mL sample and mix. Add contents to a second flask containing 5 mL each of buffer reagent and DPD indicator solution (or add about 500 mg DPD powder direct to the first flask). Titrate rapidly with standard FAS titrant until the red color is discharged (Reading N).

*c. Free chlorine in presence of bromine or iodine:* Determine free chlorine as in paragraph *a1* above. To a second 100-mL sample, add 1 mL glycine solution before adding DPD and buffer. Titrate according to paragraph *a1* above. Subtract the second reading from the first to obtain Reading A.

## 4. Calculation

For a 100-mL sample, 1.00 mL standard FAS titrant = 1.00 mg/L Cl as Cl<sub>2</sub>.

In the event that monochloramine is present with NCl<sub>3</sub>, it will be included in N, in which case obtain NCl<sub>3</sub> from 2(N-B).

Chlorine dioxide, if present, is included in A to the extent of one-fifth of its total chlorine content.

Reading	NCl <sub>3</sub> Absent	NCl <sub>3</sub> Present
A	Free Cl	Free Cl
B-A	NH <sub>2</sub> Cl	NH <sub>2</sub> Cl
C-B	NHCl <sub>2</sub>	NHCl <sub>2</sub> + ½NCl <sub>3</sub>
N	—	Free Cl + ½NCl <sub>3</sub>
2(N-A)	—	NCl <sub>3</sub>
C-N	—	NHCl <sub>2</sub>

In the simplified procedure for free and combined chlorine, only A (free Cl) and C (total Cl) are required. Obtain combined chlorine from C-A.

The result obtained in the simplified total chlorine procedure corresponds to C.

### 5. Precision and Bias

See 4500-Cl B.5.

## 4500-Cl G. DPD COLORIMETRIC METHOD

### 1. General Discussion

*a. Principle:* This is a colorimetric version of the DPD method and is based on the same principles. Instead of titration with standard ferrous ammonium sulfate (FAS) solution as in the titrimetric method, a colorimetric procedure is used.

*b. Interference:* See 4500-Cl A.3 and F.1*d*. Compensate for color and turbidity by using sample to zero photometer. Minimize chromate interference by using the thioacetamide blank correction.

*c. Minimum detectable concentration:* Approximately 10 µg/L Cl as Cl<sub>2</sub>. This detection limit is achievable under ideal conditions; normal working detection limits typically are higher.

*d. Quality control (QC):* The QC practices considered to be an integral part of each method are summarized in Table 4020:1.

### 2. Apparatus

*a. Photometric equipment:* One of the following is required:

1) *Spectrophotometer*, for use at a wavelength of 515 nm and providing a light path of 1 cm or longer.

2) *Filter photometer*, equipped with a filter having maximum transmission in the wavelength range of 490 to 530 nm and providing a light path of 1 cm or longer.

*b. Glassware:* Use separate glassware, including separate spectrophotometer cells, for free and combined (dichloramine) measurements, to avoid iodide contamination in free chlorine measurement.

### 3. Reagents

See 4500-Cl F.2*a, b, c, d, e, h, i, and j*.

### Bibliography

- Palin AT. The determination of free and combined chlorine in water by the use of diethyl-p-phenylene diamine. J Amer Water Works Assoc. 1957;49(7):873-880.
- Palin AT. Current DPD methods for disinfectant residual measurement. J Inst Water Eng. 1986;40:501-510.
- Nicolson NJ. Determination of chlorine in water, Parts 1, 2, and 3. Water Research Association. Technical Papers Nos. 29 (1965), 47 (1965), and 53 (1966).
- Palin AT. Methods for determination, in water, of free and combined available chlorine, chlorine dioxide and chlorite, bromine, iodine, and ozone using diethyl-p-phenylenediamine (DPD). J Inst Water Eng. 1967;21:537-547.
- Palin AT. Determination of nitrogen trichloride in water. J Amer Water Works Assoc. 1968;60(7):847-851.
- Palin AT. Current DPD methods for residual halogen compounds and ozone in water. J Amer Water Works Assoc. 1975;67(1):32-33.
- Great Britain Standing Committee of Analysts. Chemical disinfecting agents in water and effluents, and chlorine demand. In: Methods for the examination of water and associated materials. London (UK): Her Majesty's Stationary Office; 1980.

### 4. Procedure

*a. Calibration of photometric equipment:* Calibrate instrument with chlorine or potassium permanganate solutions.

1) Chlorine solutions—Prepare chlorine standards in the range of 0.05 to 4 mg/L from about 100 mg/L chlorine water standardized as follows: Place 2 mL acetic acid and 10 to 25 mL chlorine-demand-free water in a flask. Add about 1 g KI. Measure into the flask a suitable volume of chlorine solution. In choosing a convenient volume, note that 1 mL 0.025 N Na<sub>2</sub>S<sub>2</sub>O<sub>3</sub> titrant (see 4500-Cl B.2*d*) is equivalent to about 0.9 mg chlorine. Titrate with standardized 0.025 N Na<sub>2</sub>S<sub>2</sub>O<sub>3</sub> titrant until the yellow iodine color almost disappears. Add 1 to 2 mL starch indicator solution and continue titrating to the disappearance of blue color.

Determine the blank by adding identical quantities of acid, KI, and starch indicator to a volume of chlorine-demand-free water corresponding to the sample used for titration. Perform blank titration A or B, whichever applies, according to 4500-Cl B.3*d*.

$$\text{mg/mL Cl as Cl}_2 = \frac{(A + B) \times N \times 35.45}{\text{mL sample}}$$

where:

A = mL titrant for sample,

B = mL titrant for blank (to be added or subtracted according to required blank titration. See 4500-Cl B.3*d*), and

N = normality of Na<sub>2</sub>S<sub>2</sub>O<sub>3</sub>.

Use chlorine-demand-free water and glassware to prepare these standards. Develop color by first placing 5 mL phosphate buffer solution and 5 mL DPD indicator reagent in a clean flask

and then adding 100 mL chlorine standard with thorough mixing as described in paragraphs *b* and *c* below. Fill a photometer or colorimeter cell from the flask and read the color at 515 nm. Return the cell contents to the flask and titrate with standard FAS titrant as a check on chlorine concentration.

2) Potassium permanganate solutions—Prepare a stock solution containing 891 mg  $\text{KMnO}_4$ /1000 mL. Dilute 10.00 mL stock solution to 100 mL with reagent water in a volumetric flask. When 1 mL of this solution is diluted to 100 mL with reagent water, a chlorine equivalent of 1.00 mg/L is produced in the DPD reaction. Prepare a series of  $\text{KMnO}_4$  standards covering the chlorine equivalent range of 0.05 to 4 mg/L. Develop the color by first placing 5 mL phosphate buffer and 5 mL DPD indicator reagent in a flask and adding 100 mL standard with thorough mixing as described in paragraphs *b* and *c* below. Fill a photometer or colorimeter cell from the flask and read the color at 515 nm. Return the cell contents to the flask and titrate with FAS titrant as a check on any absorption of permanganate by reagent water.

Obtain all readings by comparison to color standards or the standard curve before use in calculation.

*b. Volume of sample:* Use a sample volume appropriate to the photometer or colorimeter. The following procedure is based on using 10-mL volumes; adjust reagent quantities proportionately for other sample volumes. Dilute the sample with chlorine-demand-free water when total chlorine exceeds 4 mg/L.

*c. Free chlorine:* Place 0.5 mL each of buffer reagent and DPD indicator reagent in a test tube or photometer cell. Add 10 mL sample and mix. Read the color immediately (Reading *A*).

*d. Monochloramine:* Continue by adding one very small crystal of KI (about 0.1 mg) and mix. If dichloramine concentration is expected to be high, instead of small crystal add 0.1 mL (2 drops) freshly prepared KI solution (0.1 g/100 mL). Read the color immediately (Reading *B*).

*e. Dichloramine:* Continue by adding several crystals of KI (about 0.1 g) and mix to dissolve. Let stand about 2 min and read the color (Reading *C*).

*f. Nitrogen trichloride:* Place a very small crystal of KI (about 0.1 mg) in a clean test tube or photometer cell. Add 10 mL sample and mix. To a second tube or cell add 0.5 mL each of buffer and indicator reagents; mix. Add contents to the first tube or cell and mix. Read the color immediately (Reading *N*).

*g. Chromate correction using thioacetamide:* Add 0.5 mL thioacetamide solution (F.2i) to 100 mL sample. After mixing, add the buffer and DPD reagent. Read the color immediately. Add several crystals of KI (about 0.1 g) and mix to dissolve. Let stand about 2 min and read the color. Subtract the first reading from Reading *A* and the second reading from Reading *C* and use in calculations.

*h. Simplified procedure for total chlorine:* Omit Step *d* above to obtain monochloramine and dichloramine together as combined chlorine. To obtain total chlorine in one reading, add the full amount of KI at the start, with the specified amounts of buffer reagent and DPD indicator. Read the color after 2 min.

## 5. Calculation

Reading	$\text{NCl}_3$ Absent	$\text{NCl}_3$ Present
<i>A</i>	Free Cl	Free Cl
<i>B-A</i>	$\text{NH}_2\text{Cl}$	$\text{NH}_2\text{Cl}$
<i>C-B</i>	$\text{NHCl}_2$	$\text{NHCl}_2 + \frac{1}{2}\text{NCl}_3$
<i>N</i>	—	Free Cl + $\frac{1}{2}\text{NCl}_3$
$2(\text{N}-\text{A})$	—	$\text{NCl}_3$
<i>C-N</i>	—	$\text{NHCl}_2$

In the event that monochloramine is present with  $\text{NCl}_3$ , it will be included in Reading *N*, in which case obtain  $\text{NCl}_3$  from  $2(\text{N}-\text{B})$ .

## Bibliography

See 4500-Cl F.6.

## 4500-Cl H. SYRINGALDAZINE (FACTS) METHOD

### 1. General Discussion

*a. Principle:* The free (available) chlorine test, syringaldazine (FACTS) measures free chlorine over the range of 0.1 to 10 mg/L. A saturated solution of syringaldazine (3,5-dimethoxy-4-hydroxy-benzaldehyde azine) in 2-propanol is used. Syringaldazine is oxidized by free chlorine on a 1:1 molar basis to produce a colored product with an absorption maximum of 530 nm. The color product is only slightly soluble in water; therefore, at chlorine concentrations greater than 1 mg/L, the final reaction mixture must contain 2-propanol to prevent product precipitation and color fading.

The optimum color and solubility (minimum fading) are obtained in a solution having a pH between 6.5 and 6.8. At a pH <6, color development is slow and reproducibility is poor. At a pH >7, the color develops rapidly but fades quickly. A buffer is required to maintain the reaction mixture pH at approximately 6.7.

Take care with waters of high acidity or alkalinity to assure that the added buffer maintains the proper pH.

Temperature has a minimal effect on the color reaction. The maximum error observed at temperature extremes of 5 and 35 °C is  $\pm 10\%$ .

*b. Interferences:* Interferences common to other methods for determining free chlorine do not affect the FACTS procedure. Monochloramine concentrations up to 18 mg/L, dichloramine concentrations up to 10 mg/L, and manganese concentrations (oxidized forms) up to 1 mg/L do not interfere. Trichloramine at levels above 0.6 mg/L produces an apparent free chlorine reaction. Very high concentrations of monochloramine ( $\geq 35$  mg/L) and oxidized manganese ( $\geq 2.6$  mg/L) produce a color with syringaldazine slowly. Ferric iron can react with syringaldazine; however, concentrations up to 10 mg/L do not interfere. Nitrite ( $\leq 250$  mg/L), nitrate ( $\leq 100$  mg/L), sulfate ( $\leq 1000$  mg/L), and chloride ( $\leq 1000$  mg/L) do not interfere. Waters with high hardness ( $\geq 500$  mg/L) produce

a cloudy solution that can be compensated for by using a blank. Oxygen does not interfere.

Other strong oxidizing agents, such as iodine, bromine, and ozone, produce a color.

*c. Minimum detectable concentration:* The FACTS procedure is sensitive to free chlorine concentrations of 0.1 mg/L or less.

*d. Quality control (QC):* The QC practices considered to be an integral part of each method are summarized in Table 4020:1.

## 2. Apparatus

*Colorimetric equipment:* One of the following is required:

*a. Filter photometer,* providing a light path of 1 cm for chlorine concentrations  $\leq 1$  mg/L or a light path from 1 to 10 mm for chlorine concentrations above 1 mg/L; also equipped with a filter having a band pass of 500 to 560 nm.

*b. Spectrophotometer,* for use at 530 nm, providing the light paths noted above.

## 3. Reagents

*a. Chlorine-demand-free water:* See 4500-Cl C.3*m*. Use to prepare reagent solutions and sample dilutions.

*b. Syringaldazine indicator:* Dissolve 115 mg 3,5-dimethoxy-4-hydroxybenzaldehyde azine in 1 L 2-propanol.

*c. 2-Propanol:* To aid in dissolution use ultrasonic agitation or gentle heating and stirring. Redistill reagent-grade 2-propanol to remove chlorine demand. Use a 30.5-cm Vigreux column and take the middle 75% fraction. Alternatively, chlorinate good-quality 2-propanol to maintain a free residual overnight; then expose to UV light or sunlight to dechlorinate. **Caution: 2-Propanol is extremely flammable.**

*d. Buffer:* Dissolve 17.01 g  $\text{KH}_2\text{PO}_4$  in 250 mL water; pH is about 4.4. Dissolve 17.75 g  $\text{Na}_2\text{HPO}_4$  in 250 mL water; the pH is about 9.9. Mix equal volumes of these solutions to obtain FACTS

buffer, pH 6.6. Verify pH with pH meter. For waters containing considerable hardness or high alkalinity other pH 6.6 buffers can be used, for example, 23.21 g maleic acid and 16.5 mL 50% NaOH per liter of water.

*e. Hypochlorite solution:* Dilute household hypochlorite solution, which contains about 30 000 to 50 000 mg/L Cl equivalent, to a strength between 100 and 1000 mg/L. Standardize as directed in 4500-Cl G.4*a*1.

## 4. Procedure

*a. Calibration of photometer:* Prepare a calibration curve by making dilutions of a standardized hypochlorite solution (4500-Cl.H.3*e*). Develop and measure colors as described in paragraph *b* below. Check the calibration regularly, especially as the reagent ages.

*b. Free chlorine analysis:* Add 3 mL sample and 0.1 mL buffer to a 5-mL-capacity test tube. Add 1 mL syringaldazine indicator, cap the tube, and invert twice to mix. Transfer to a photometer tube or spectrophotometer cell and measure absorbance. Compare absorbance value obtained with the calibration curve and report the corresponding value as milligrams free chlorine per liter.

## Bibliography

Bauer R, Rupe CO. Use of syringaldazine in a photometric method for estimating "free" chlorine in water. *Anal Chem.* 1971;43(3):421-425.

Cooper WJ, Sorber CA, Meier EP. A rapid specific free available chlorine test with syringaldazine (FACTS). *J Amer Water Works Assoc.* 1975;67(1):34-39.

Cooper WJ, Gibbs PH, Ott EM, Patel P. Equivalency testing of procedures for measuring free available chlorine: amperometric titration, DPD, and FACTS. *J Amer Water Works Assoc.* 1983;75(12): 625-629.

# 4500-Cl I. IODOMETRIC ELECTRODE TECHNIQUE

## 1. General Discussion

*a. Principle:* This method involves the direct potentiometric measurement of iodine released on the addition of potassium iodide to an acidified sample. A platinum-iodide electrode pair is used in combination with an expanded-scale pH meter.

*b. Interference:* All oxidizing agents that interfere with other iodometric procedures interfere. These include oxidized manganese and iodate, bromine, and cupric ions. Silver and mercuric ions above 10 and 20 mg/L interfere.

*c. Quality control (QC):* The QC practices considered to be an integral part of each method are summarized in Table 4020:1.

## 2. Apparatus

*a. Electrodes:* Use either a combination electrode consisting of a platinum electrode and an iodide ion-selective

electrode or 2 individual electrodes. Both systems are available commercially.

*b. pH/millivolt meter:* Use an expanded-scale pH/millivolt meter with 0.1 mV readability or a direct-reading selective ion meter.

## 3. Reagents

*a. pH 4 buffer solution:* See 4500-Cl C.3*e*.

*b. Chlorine-demand-free water:* See 4500-Cl C.3*m*.

*c. Potassium iodide solution:* Dissolve 42 g KI and 0.2 g  $\text{Na}_2\text{CO}_3$  in 500 mL chlorine-demand-free reagent water. Store in a dark bottle.

*d. Standard potassium iodate, 0.002 81 N:* Dissolve 0.1002 g  $\text{KIO}_3$  in chlorine-demand-free, reagent water and dilute to 100 mL. Each 1.0 mL, when diluted to 100 mL, produces a solution equivalent to 1 mg/L as  $\text{Cl}_2$ .

#### 4. Procedure

*a. Standardization:* Pipet into three 100-mL stoppered volumetric flasks 0.20, 1.00, and 5.00 mL standard iodate solution. Add to each flask, and a fourth flask to be used as a reagent blank, 1 mL each of acetate buffer solution and KI solution. Stopper, swirl to mix, and let stand 2 min before dilution. Dilute each standard to 100 mL with chlorine-demand-free reagent water. Stopper, invert the flask several times to mix, and pour into separate 150-mL beakers. Stir gently without turbulence, using a magnetic stirrer, and immerse electrodes in the 0.2-mg/L (0.2-mL) standard. Wait for the potential to stabilize and record the potential in mV. Rinse the electrodes with chlorine-demand-free water and repeat for each standard and for the reagent blank. Prepare a calibration curve by plotting, on semilogarithmic paper, potential (linear axis) against concentration. Determine the apparent chlorine concentration in the reagent blank from this graph (Reading B).

*b. Analysis:* Select a volume of sample containing no more than 0.5 mg chlorine. Pipet 1 mL acetate buffer solution and 1 mL KI into a 100-mL glass-stoppered volumetric flask. Stopper, swirl and let stand for at least 2 min. Adjust the sample pH to 4 to 5, if necessary (mid-range pH paper is adequate for pH measurement), by adding acetic acid. Add the pH-adjusted sample to a volumetric flask and dilute to the mark. Stopper and mix by inversion several times. Let stand for 2 min. Pour into a 150-mL beaker, immerse the electrode(s), wait for the potential to stabilize, and record. If the mV reading is greater than that

recorded for the 5-mg/L standard, repeat analysis with a smaller volume of sample.

#### 5. Calculation

Determine chlorine concentration (mg/L) corresponding to the recorded mV reading from the standard curve. This is Reading A. Determine total residual chlorine from the following:

$$\text{Total residual chlorine} = A \times 100/V$$

where  $V$  = sample volume in milliliters. If total residual chlorine is below 0.2 mg/L, subtract the apparent chlorine in reagent blank (Reading B) to obtain the true total residual chlorine value.

#### Bibliography

- Jenkins RL, Baird RB. Determination of total chlorine residual in treated wastewaters by electrode. *Anal Letters*. 1979;12:125-141.
- Dimmock NA, Midgley D. Determination of total residual chlorine in cooling water with the Orion 97-70 ion selective electrode; Report RD/L/2159N81. United Kingdom: Central Electricity Generating Board, 1981.
- Synnot JC, Smith AM. Total residual chlorine by ion-selective electrode—from bench top to continuous monitor. In: Pawlowski L, Alaerts G, Lacy WJ, eds. *Chemistry for protection of the environment*. Elsevier; 1986, p. 777-791. (Studies in Environmental Science, Vol. 29)

## 4500-ClO<sub>2</sub>

### CHLORINE DIOXIDE

Approved by Standard Methods Committee, 2000. Editorial revisions, 2021. Joint Task Group: Robert P. Fisher (chair), James M. Gindelberger, Gilbert Gordon, Robert C. Hoehn, Wayne B. Huebner, Frances Y. Saunders.

## 4500-ClO<sub>2</sub>

### A. INTRODUCTION

Because the physical and chemical properties of chlorine dioxide resemble those of chlorine in many respects, read the entire discussion of Section 4500-Cl, Chlorine (Residual) before attempting a chlorine dioxide determination.

#### 1. Occurrence and Significance

Chlorine dioxide, ClO<sub>2</sub>, has been used widely as a bleaching agent in the paper and pulp industry. It has been applied to water supplies to combat tastes and odors due to phenolic-type wastes, actinomycetes, and algae, as well as to oxidize soluble iron and manganese to a more easily removable form. It is a disinfectant, and some results suggest that it may be stronger than free chlorine or hypochlorite.

Chlorine dioxide is a deep yellow, volatile, unpleasant-smelling gas that is toxic and under certain conditions may react explosively. Handle with care in a vented area. The use of odor to warn

of exposure to concentrations of health significance may not be adequate.

There are several methods of generating ClO<sub>2</sub>. For laboratory purposes the acidification of a solution of sodium chlorite followed by suitable scrubbing and capture of the released gaseous ClO<sub>2</sub> is the most practical. **Caution: Sodium chlorite is a powerful oxidizer; keep out of direct contact with oxidizable material to avoid the possibility of explosion.**

#### 2. Selection of Method

The iodometric method (4500-ClO<sub>2</sub> B) gives a very precise measure of the total available strength of a solution in terms of its ability to liberate iodine from iodide. However, chlorine dioxide, chlorine, chlorite, and hypochlorite are not distinguished easily by this technique. It is designed primarily, and best used, for standardizing ClO<sub>2</sub> solutions needed for preparing temporary standards. It often is inapplicable to industrial wastes.